


# LANC Camcorder Control Board User Switch Settings

Copyright 2003, PixController <http://www.pixcontroller.com/>, all rights reserved.

The User Control Switch (SW1) will let you customize how the LANC Camcorder Control Board will trigger the Camcorder. Here you can adjust the time delay between pictures, operating only at day, night, or 24 hours, setting up a walk-test mode for testing PIR range/area, set how long the camcorder will record, and turning the control board LED's on or off.

**Note: You must reboot the controller for changes to take place.**



*Modes of Switch Operation*


## Default Setting




*No Delay between pictures, 24 Hour Recording, 30 Seconds of recording time, Control LED On, PIR LED On.*

## Delays Between Video Shots Setting


Switches 1, 2, and 3 control the delays between video shots.




*No Delay*




*10 Seconds Delay*




*30 Seconds Delay*




*1 Minute Delay*




*5 Minute Delay*



*10 Minute Delay*




*30 Minute Delay*




*60 Minute Delay*

## Day/Night Operation Settings

Switches 4 and 5 control Daylight, Night Time, and 24 Hour recording or pictures.



*24 Hour Operation*



*Night Only Operation*




*Day Only Operation*

## PIR Walk-Test Mode

On boot up of the Digital-Scout this setting will put the unit into a PIR Walk-Test mode. Here you can check out the PIR detection area without having the unit take photos. When booting the Digital-Scout into this mode the RED Control LED and Green PIR LED will stay on for about 30 seconds. This is when the PIR is warming up. After this period of time has expired you are free to walk and test the PIR area.


**Note:** To put the Digital-Scout back into "Photo Taking Mode" change the switch settings of switch 4 and 5 to one of the three options above under the Day/Night Operation Setting, and power the Digital-Scout unit Off and On from the external power switch.




*PIR Walk-Test Mode*

## Camcorder Recording Time


Switch 6 and 7 sets the recording time of the Camcorder on a PIR event.




*30 Seconds*



*1 Minute*




*2.5 Minutes*




*5 Minutes*

### **Control LED On/Off Setting**

Switch 8 sets if the Control LED (Red LED) is to be used or not. Note, the control LED will always be on during the Power-Up Phase, or when in Walk-Test Mode.




*Control LED On*




*Control LED Off*

### **PIR LED On/Off Setting**

Switch 9 sets if the PIR LED (Green LED) is to be used or not.



*PIR LED On*



*PIR LED Off*